Plug-in motifs with Cricut

Instructions No. 2919

Difficulty: Advanced

Working time: 1 hour 30 Minutes

With a few simple steps, we'll show you how to create beautiful Christmas trees and a charming house with the Cricut Maker 3. Your Christmas decorations will be unique, magical and a real eye-catcher on any window sill or table!



Cricut Design Space

Before we start our craft project, we open the Cricut Design Space and switch to the "Workspace". In the left bar of the Design Space, click on "Shapes". From the available options, we select triangles, squares and rectangles to design the Christmas trees and the house. In order for our individual elements to be cut out as a whole, we need to join them together. To do this, select the fir and the trunk, for example, and click on "Combine" at the bottom right and then on "Connect".

Arrangement and preparation

Click on "Create" at the top right of the Design Space. Select the mat and the desired length of the mat. Now you can arrange your motifs on the mat as you wish. Be creative! Place the lime wood on the mat. It is advisable to additionally fix the wood on the sides with adhesive tape to prevent it from slipping. Connect the plotter and insert the prepared mat. Click on "Continue" and follow the plotter's instructions. Insert the mat and start the plotting process.

Creative conclusion

While the plotter is working, you have time to paint the pegboard and one of the Christmas trees with the craft paints mentioned above. Design the tag according to your ideas with a lettering of your choice. Once the plotter has done its work, take the cut-out pieces and insert them into the pegboard. The result will enrich your Christmas decorations!



Article information:

Article number	Article name	Qty
26748	Cricut Maker 4	1
281263	Connector strip with 3 rails	1
610439	VBS Bamboo wood spikes, 50 pieces	1
27509	VBS Craft paint, 50 mlOlive	1
111065	VBS Handicraft glue	1
20571	STAEDTLER Fine transparency marker "Lumocolor - non-permanent"	1