

Table easel as cookbook stand

Instructions No. 558

Practical: On this cookbook stand, the recipe stays open exactly on the page you need for cooking. The timeless **country house look** is created by playful bobbin lace and MDF decors, which are simply glued on, and by the dark wiped edges.

Here's **how it works**

Disassemble the Easel into its individual components, saw off the middle bar at the desired height.

All individual parts, the wing screws, hinges and two MDF-decors paint white opaque and let dry.

For an antique effect, wipe over the edges with Ink Pads

Reassemble the Easel .

Glue the bobbin lace with tape-Ribbon on the upper and lower crossbar and on the slider.

Cut ten 20 cm long pieces of Cord , fold them over in the middle and wrap them with the rest of the Cord to form a tassel. Fix the ends with hot glue.

Cut the end of the tassel straight.

Cut the second glitter cord into three pieces of the same length, thread it halfway through the loop of the tassel and braid a plait with two strands of each.

Glue the plait with hot glue on the slider and over it a MDF-decoration.

Glue the second decor in front of the shelf.



This idea is timelessly beautiful!

Some Article are unfortunately no longer available

But this idea is too good to withhold from you. We would be happy to continue to present it to you - let yourself be inspired!



Must Have



[VBS Table easel](#)

● **928,99 Kč**

[Item details](#)

Quantity: [Add to cart](#) 

Article information:

Article number	Article name	Qty
480024	Keraflott Relief Casting Powder, White1 kg	1
750028-70	Marabu decorative lacquer, 50 mlWhite	1
542708-06	Staz-On Stamp padDark brown	1
418454	VBS Crochet ribbon "Cream", 10 mm, 10 m	1
644303-03	VBS Double page Adhesive tape3 mm	1
120371-10	VBS Flat brush "Easy-Brush"Size 10/10 mm	1
21904	VBS Scissors "Soft-Grip", set of 2	1
130288	Handicraft saw	1
51163	Hot glue gun, 15-80 Watt	1